


## Directions For Removing / Reattaching Skirt Door Panel

### Directions For Removing Skirt Door Panel

1. Remove snap caps, using small plastic putty knife or something that will not scratch the surface, slide underneath cap and pop out.

2. Unscrew philips screws until skirt door panel is released. Snap cap washer will come off with screw.



### Reattaching Skirt Door Panel

1. Place door panel back in frame, check for proper alignment

2. Put snap cap washer on screw and place in hole on door. Tighten screw down snug. DO NOT over tighten.

3. Snap the snap caps back into place.

