



Use and Care Instructions

We Love to Spoil Our Customers

1003 S. Hazel St. Glenwood, IA 51534-2001 (712) 527-1800 FAX (712) 527-4331 Customer Toll Free 1-800-795-1812

Operating your Whirlpool:

Before using your tub for the first time, clean the tub and wipe out any debris.

Fill the tub at least two inches above the highest jet before turning on the pump. Exposed jets will cause excessive splashing. **Never run the unit dry** - this can damage the pump.

Do not leave children unattended in or around an operating whirlpool.

Never have any electrical device within reach.

Never put your head under water while operating the whirlpool. Hair can be caught in suction inlet and cause injury.

High foaming agents (bubble baths) should not be used when the pump is operating. Take your whirlpool first, then use soap like a standard tub. Using oils can cause build-up in the system and may require extra cleaning.

Cleaning your Whirlpool:

For normal cleaning, use a soft sponge with warm water and cleaner. Make sure the cleaner does not contain abrasives, ammonia or any harsh additives. Many non-abrasive cleaning agents designed for plastics and fiberglass are now on the market.

One way to keep your whirlpool looking like new is with a little preventative maintenance. After using your tub, take a moment and wipe it out with a towel. This habit prevents usual film build-up. Products such as Gel-Gloss can be applied to the unit to increase and maintain the shine.

The whirlpool system should be flushed once a month using the following procedural sequence:

- Set air controls to fully closed position.
- Fill tub with hot water until water covers jets.
- Add 2 teaspoons of a low-foaming automatic dishwasher detergent, such as Cascade, and 4 ounces of household bleach, (Clorox).
- Run whirlpool unit for 10 to 15 minutes.
- Drain tub and fill with cold water until water covers jets.
- Run whirlpool unit another 5-10 minutes then drain tub.